

# 80.003.744 SHOCK ABSORBER MOUNTING KIT



## 80.003.744

### SHOCK ABSORBER MOUNTING KIT

Fitting Position: Rear Axle both sides

**VEHICLE**

Volvo

**OE**

3091744